



# ARTPLASTICS

Innovative Plumbing Fittings

## XP100 Extenda Pan

Solves a multiple of difficult installation situations through the use of its unique and patented extended channel.



### Features include

- ✓ Fully Watermark Approved product.
- ✓ Allows for variable offsets between the sewer pipe and the pan spigot in 10mm increments up to 100mm. Never again curse a misaligned sewer pipe!
- ✓ Avoids major jack hammering of the slab and saves hours of installation hassles.
- ✓ Ideal solution for retrofits of new water efficient pans with only minor rebating required.
- ✓ May be installed prior to pour to provide flexibility in subsequent pan choice and installation.

### Product Code:

31902- 100mm Extenda Pan 0-100mm Offset



## Art Plastics

134 Gilba Road Girraween, NSW 2145

Email: sales@artplastics.com.au

Website: www.artplastics.com.au

Phone: 02 9896 7760

Fax: 02 9636 2498

# XP100 Extenda Pan

## XP100 Pan Connector Installation Instructions:

- Mark and measure the offset required between the pan spigot and the sewer pipe.
- Use a 79mm hole saw to cut a hole in the channel lid of the XP100 pan connector using the series of guide holes to get the required offset. N.B. These offset guide hole positions relate directly to the fixing holes along the outside for attachment of the poop scoop, so accurate centring is vital for the tow components to fit together. It is not possible to drill the hole in between these guide holes.
- Lubricate and position the O-ring in the groove of the poop scoop.
- Fix the poop scoop onto the channel lid of the XP100 pan connector using the four stainless steel nuts included, spring washers and bolts. N. B. The bolt comes up from below the channel lid, through the associated hole in the poop scoop and then through a spring washer and is fixed by the Nut going on top (see diagram)
- Dummy fit the toilet onto the assembly to determine the extent of chipping required. N.B. The top of the pan seal should be level as the XP100 incorporates a 5deg fall in the body of the unit.
- Position the toilet pan over the XP100 ensuring full engagement between the spigot and the pan seal. Use lubrication if necessary.
- Fit the toilet pan to the floor as per the pan instructions.
- The XP100 Extenda Pan may be installed prior to pour to provide flexibility in subsequent pan choice and installation. If you prefer this option, the undrilled body assembly should be wrapped in lagging foam during the pour to allow extraction at a later date when the pan is being installed so that the hole can be drilled and poop scoop fitted.



## CONTACT US

### ■ New South Wales & Victoria

#### Art Plastics

Phone: 02 9896 7760

Fax: 02 9636 2498

#### New South Wales

Colin Jay

Phone: 0400 080 591

#### Victoria

Mark Thomas

Phone: 0438 665 444

### ■ South Australia

#### Steve Molloy Agencies

Phone: 08 8352 8600

Fax: 08 8352 8622

### ■ Western Australia

#### Pride Industries

Phone: 08 9272 6511

Fax: 08 9272 3427

### ■ Queensland & NT

#### Collis Marketing Services

Phone: 07 3805 6664

Fax: 07 3805 6668

### ■ Tasmania

#### Wholesale Products

Phone: 03 6273 3455

Fax: 03 6273 1901